Downhill

Field Notch Sheeting Angle RA1 at Shop Welded Purlin Clips when Offset is 4"

Purlin Strut (When required)

Purlin

Purlin

Frame Rafter

Offset
4" (w/8" Girts)
5" (w/10" Girts)
6" (w/12" Girts)

Shop Welded Clip

(2) $\frac{1}{2}$"⌀ Bolts with $\frac{1}{2}$" Washer WFH500 located slot side

Sheeting Angle RA1
Attach to each Purlin with (1) Fastener #1B
$\frac{1}{4}$"−14 x 1$\frac{1}{4}$" DP3

Flange Brace, may be one or both sides of Rafter. See "Frame Cross Section" for requirements.

Typical Flush Girt attachment, attach with (2) $\frac{1}{2}$"⌀ Bolts to Shop Welded Clip (See "Transverse Partition Framing Elevation" for locations)

Sheeting Clip
CL292 or PC30_
(1) Fastener #12A
12−14 x 1" DP3
at each end

Flush Partition Column
(See "Transverse Partition Framing Elevation" for locations and Flange Brace requirements, if required)

Field Cut Partition Base Framing at Column when required

Partition Base Framing
Standard Base Angle RA1 shown, may vary. (See "Transverse Partition Framing Elevation" for requirement.)

$\frac{1}{4}$"⌀ Anchor (Min.)
60" o.c. (Max.)
Not by Bldg. Mfr.

Zee Girts shown, attachment similar for Cee or Zee Girt with outer flange toed up.