

# Top Running Crane on Crane Bracket

## Crane Bumper End Stop not provided by Building Manufacturer

Page  
**PF07003**

Date  
**Sep '12**

Rev.  
**02**

See PF07006B for  
required Crane Beam  
Tie-Back to Column.  
(Tie-Back Angle shown)

Crane Bumper End Stops and Connections to  
Crane Beam to be provided by the Crane  
System Supplier or Crane Rail Supplier.  
Connections to meet all requirements of AISC.  
Field locate and attach.

Crane Rail Attachment

Crane Rail

SA3\_ Crane  
Angle Brace

BT\_\_ Crane Beam

Exterior Frame Column shown  
and Interior Frame Column  
similar. (Shape may vary)

Girts and Bracing  
not shown for clarity

See PF07001 for  
Notes, Materials and  
additional Information.

